
Ladders

RIB LADDER







Hang mounting Hung on the tube and tightened with safety bands.



Comfortable steps



Hook fittings The ladder is attached to the hull with hook fitting.



Key hole fitting Optional fittings.







The RIB ladder is resting on the boat's tube and is secured with two straps.



Art	L (mm)	F (mm)	B (mm)	Tube diameter, boat (mm)	Folding
RIB400	868	375	340	400	Telescopic
RIB500	1160	410	350	500	Telescopic