







## Pick-up Fender

	 Diameter cm	 Length cm	 KG
1.	15	35	0.7
2.	18	40	0.9






## Dumpy Fender

	 Diameter cm	 Length cm	 KG
1.	15	30	0.7
2.	18	36	0.9



## Pear Fender

	 Diameter cm	 Length cm	 KG
2.	15	38	0.7
3.	18	48	1.1
4.	22	68	2.1



## Ring Fender

	 Diameter cm	 Length cm	 KG
	10	33	0.9



### Available COLOURS:



## Majoni Keyrings

Keeps your key floating. With stainless steel ring.  
Fenders are available with your own logo!



### Valve

Our brass valve for easy inflation and deflation.



### Adaptor

For easy inflation and deflation with a bicycle or car tire pump.



For deflating just push a pen slightly in the valve to let the air out. When a valve is leaking you don't have to replace your fender. You can replace the valve with turning in a bolt M3 (or a woodscrew) and pull it out with a pair of tongs. After inspecting you can push a valve back in the tube with your hand or a pen.